



Installation Guide

1. The first step is to measure the area and decide how much grass you will need.
2. Remove old lawn or paving stones.
3. Compact the ground using a vibrating plate, which can be hired at an equipment hire centre.
4. Apply a heavy duty weed membrane to area.
5. Lay the sub-base using a 6mm stone aggregate; between 25mm (1 inch) and 75mm (3 inch) thickness is sufficient. If you plan to use timber edging, fit this now, ensuring it is no higher than the final grass line otherwise drainage may be compromised
6. Spread and compact sub-base using vibrating plate
7. Lay a fine layer of sand, less than 6mm depth; ideally a slight slope should be made towards the edge of the lawn.
8. Lay grass on top, being careful not to move sand (do not drag artificial grass in place). Leave for 2 to 3 hours to settle. This helps to stop any creasing or wrinkling.
9. Cut and trim your artificial grass to size.
10. Make the joins using the correct type of seaming tape and glue; outdoor tape should be used.
11. Apply any natural stone or paving edges and then fix artificial grass using landscaping nails every 50mm (2 inches) or so.